


ER-600

IRC CABLE CONNECTION



NO	CONNECTOR "A"	DESCRIPTION	CONNECTOR "B"
1	1	TPTX -	1
2	2	TPTX -	2
3	3 (NO USE)	N.C (NO USE)	3 (NO USE)
4	4 (NO USE)	N.C (NO USE)	4 (NO USE)
5	5	TPTX +	5
6	6	TPTX +	6