


Quick Start Guide PP-82



Packing List

Standard Accessories







Power Adapter

Power Cord







CD

Quick Start Guide

USB Cable





Roll Paper

Serial Cable








Beam Cover


Wall Hanging Loading

Appearance and components

■ Front View



■ Rear View








Paper Loading

1. Press the cover open button to open the printer cover.




2. In the correct direction of the roll paper, install the roll paper.






3. Pull out some roll paper and close the printer cover.




4. Tear the extra paper in the direction of printer.



Power Supply

- 1. Make sure the printer is in "OFF".
- 2. Connect power adapter to printer.
- 3. Connect power adapter to power cord.
- 4. Plug the other side of power cord into the socket nearby.



Interface

