How do loss and delay occur?

packets *queue* in router buffers

- packet arrival rate to link exceeds output link capacity
- packets queue, wait for turn



Four sources of packet delay

- 1. nodal processing:
  - check bit errors
  - determine output link
- 2. queueing
  - time waiting at output link for transmission
  - depends on congestion level of router



Delay in packet-switched networks

3. Transmission delay:
- R=link bandwidth (bps)
- L=packet length (bits)
- time to send bits into link = L/R

4. Propagation delay:
- d = length of physical link
- s = propagation speed in medium (~2.8×10^8 m/sec)
- propagation delay = d/s

Note: s and R are *very* different quantities!



Caravan analogy



- cars "propagate" at 100 km/hr
- toll booth takes 12 sec to service car (transmission time)
- car~bit; caravan ~ packet
- Q: How long until caravan is lined up before 2nd toll booth?
- Time to "push" entire caravan through toll booth onto highway = 12*10 = 120 sec
- Time for last car to propagate from 1st to 2nd toll both: 100km/(100km/hr)= 1 hr
- A: 62 minutes

Caravan analogy (more)



- Cars now "propagate" at
  1000 km/hr
- Toll booth now takes 1 min to service a car
- Q: Will cars arrive to 2nd booth before all cars serviced at 1st booth?

- Yes! After 7 min, 1st car at 2nd booth and 3 cars still at 1st booth.
- 1st bit of packet can arrive at 2nd router before packet is fully transmitted at 1st router!
  - See Ethernet applet at AWL Web site

Let's analyze it!

- http://media.pearsoncmg.com/aw/aw_kurose_network_2/applets/transmission/delay.html

Nodal delay

$$d_{\text{nodal}} = d_{\text{proc}} + d_{\text{queue}} + d_{\text{trans}} + d_{\text{prop}}$$

- d_{proc} = processing delay
  - typically a few microsecs or less
- d_{queue} = queuing delay
  - depends on congestion
- d_{trans} = transmission delay
  - = L/R, significant for low-speed links
- d_{prop} = propagation delay
  - a few microsecs to hundreds of msecs

Introduction 1-67

Queueing delay (revisited)

- R=link bandwidth (bps)
- L=packet length (bits)
- a=average packet arrival rate

traffic intensity = La/R



- La/R ~ 0: average queueing delay small
- La/R -> 1: delays become large
- La/R > 1: more "work" arriving than can be serviced, average delay infinite!

Introduction 1-68

Packet loss

- queue (aka buffer) preceding link in buffer has finite capacity
- packet arriving to full queue dropped (aka lost)
- lost packet may be retransmitted by previous node, by source end system, or not at all



Packet loss

- Let's try it out…
- http://media.pearsoncmg.com/aw/aw_kurose_network_2/applets/queuing/queuing.html
- … submit your summary analysis via elearning platform!

Throughput

- *throughput:* rate (bits/time unit) at which bits transferred between sender/receiver
  - *instantaneous:* rate at given point in time
  - *average:* rate over long(er) period of time



Throughput (more)

- $R_s < R_c$ What is average end-end throughput?



- $R_s > R_c$ What is average end-end throughput?



bottleneck link

link on end-end path that constrains end-end throughput

Throughput: Internet scenario

- per-connection end-end throughput: $\min(R_c,R_s,R/10)$
- in practice: R_c or R_s is often bottleneck



10 connections (fairly) share backbone bottleneck link R bits/sec

Problems to solve...

- In the following problems, we are sending a **30 Mbit** MP3 file from a source host to a destination host. **All links** in the path between source and destination **have a transmission rate of 10 Mbps**. Assume that the **propagation speed** is **2 * 10^8 m/sec**, and the **distance** between **source** and **destination** is **10,000 km**.